3. Label Printing

Connect and configure supported DYMO label printers.

- How to enable a DYMO label printer and choose label size
- How to troubleshoot DYMO label printing

How to enable a DYMO label printer and choose label size

Enable DYMO printing on a computer connected to a supported DYMO printer and running the required DYMO software.

Configure DYMO

1. Connect and power on the DYMO printer.
2. Confirm DYMO Connect is installed and can see the printer.
3. Open **Settings > Devices & Hardware**.
4. Enable **DYMO Printer**.
5. Select **Big**, **Small**, or **Mini** to match the installed label roll.
6. Save the settings.
7. Print a test label from the workflow that will use it.

This is a device-specific setting and must be configured on each computer that prints labels.

How to troubleshoot DYMO label printing

If a DYMO label does not print correctly, verify the hardware, software, and label configuration in order.

Troubleshooting checklist

- Confirm the printer is powered on and connected to this computer.
- Open DYMO Connect and verify that it recognizes the printer.
- Confirm DYMO is enabled in Devices & Hardware.
- Match the selected label size to the roll installed in the printer.
- Check label orientation and clear any jam.
- Reload RepairNest POS after reconnecting the printer.
- Try a controlled test label before printing a large batch.