How to connect a Star WebPRNT receipt printer

Use Star WebPRNT when a supported Star receipt printer is available over the network.

Connect the printer

1. Connect the printer to the same reachable network as the register.
2. Open **Settings > Devices & Hardware**.
3. Disable embedded PDF receipt mode when it is enabled.
4. Enable **Star WebPRNT**.
5. Enter the printer host name or IP address.
6. Save the settings.
7. Print a controlled test receipt.

If it does not print

- Confirm the printer is powered on and online.
- Verify the host or IP address.
- Confirm the register can reach the printer network.
- Check the selected paper size.

Revision #1
Created 2026-09-13 03:00:50 UTC by Sunny
Updated 2026-09-13 03:00:52 UTC by Sunny